







#### **INDICATIONS FOR USE**

The IO FiX Intraosseous Fixation System is intended for reduction and internal fixation of arthrodeses, osteotomies, intra- and extrarticular fractures and nonunions of the small bones and joints of the foot and ankle. The two-part construct is specifically intended for use in Talonavicular, Calcaneocuboid, Metatarsocuneiform, and ankle arthrodesis, as well as Metatarsal Osteotomies.

**NOTE:** This technique guide illustrates the placement of an IO FiX 2.0 construct for a Talonavicular Fusion.

## **Implant Specifications**







IO FiX 2.0 X-Posts	Angle	X-Post Lengths	Major Diameter	Minor Diameter
Small X-Post (aqua)	60°	15,20,25,30mm	4.5mm	3.0mm
Medium X-Post (blue)	60°	20,25,30mm	6.5mm	4.5mm

Lag Screw	Screw Lengths	Major Diameter	Minor Diameter	Thread Length
4.3mm Tapered Locking	26-40 (x2 mm increments) 45, 50	4.3mm	2.8mm	Length-15mm
5.0mm Tapered Locking	26-40 (x2 mm increments) 45, 50	5.0mm	3.4mm	Length-15mm
4.5mm Low Profile Headed	26-40 (x2 mm increments) 45, 50	4.5mm	3.0mm	Length-15mm

### **Locking Construct**



### **Non-Locking Polyaxial Construct**








### **Exposure and Joint Preparation**

The standard incision, dissection, joint exposure and denuding techniques for arthrodesis should be performed as per the surgeon's preference.


### STEP 1: X-Post Wire Placement


The placement of the X-Post dictates the Tapered Locking Screw trajectory as they interlock at a 60° angle. Utilize the Alignment Guide to assist with X-Post placement:

- Place a 1.6mm Guidewire through the joint in the ideal screw trajectory
- Confirm the placement of this wire with fluoroscopy (AP and Lateral) as it represents screw placement



- Place the Alignment Guide over the Guidewire and slide it towards the joint
- Place the X-Post Guidewire through the Alignment Guide 10mm from the joint line (this ensures clearance of the screw threads past the joint line)
- If X-Post is placed greater than 10mm from joint, over drill the new cortex with a 4.5mm drill
- Confirm X-Post Guidewire placement with fluoroscopy (AP and Lateral) and then remove the initial screw trajectory Guidewire






X-Post Guidewire holes are located 10mm back from the edge of the Alignment Guide




# STEP 2: Determine X-Post Length

• Place the Depth Gauge (Direct Depth) over the Guidewire and down to bone to determine the length of the X-Post



# STEP 3: Bone Preparation for the X-Post Drill & Countersink

- Select the appropriate Cannulated Drill and Countersink based on the desired X-Post
- Place the Cannulated Drill over the Guidewire and advance to the pre-determined X-Post length
- Advance the appropriate sized Countersink until the laser mark comes in contact with the cortical bone









### STEP 4: X-Post Placement

- Align the X-Post and 3.0 Hex Driver with the laser marked arrow and black line as depicted below
- Insert the X-Post until flush with the cortex. The laser marking on the driver/implant should orient towards the intended fusion area

**TIP:** Place a wire through the hole on the driver, as shown, to confirm and fine tune screw trajectory.







# STEP 5: Clearing Step

It is critical to create an accurate path to allow for the proper orientation of the Drill Guide and subsequent Screw.

- Remove the 3.0 Hex Driver
- Fully seat the Clearing Jig into the X-Post (align laser marking on jig with the implant)
- Advance the Clearing Trephine (power) through the jig and down to bone
- The trephine has a positive stop and will clear the exact amount of bone at the ideal 60° orientation





Non-Locking Screw

**NOTE:** For Headed (Non-Locking) screw, additional clearing with the Clearing Tool or rongeurs may be required to allow for proper screw trajectory.






# STEP 6: Guidewire Placement (Locking Screws)

#### **Tapered Locking Screw Placement**




- Assemble the "TOP HAT" Guidewire and Drill Guide:
  - Thread the 1.6 Guidewire Guide into the appropriate Drill Guide
- · Insert the Drill Guide assembly into the eyelit of the X-Post
- Advance a 1.6mm Guidewire through the Top Hat Drill Guide
- · Verify Guidewire position and depth with fluoroscopy
- Determine the length of the Screw by measuring the Guidewire with the "Lag screw + Wire guide" side of the Depth Gauge over the Guidewire and down to the top of the Drill Guide Assembly.



# STEP 6a: Guidewire Placement (Non-Locking Screw)

The Low Profile Headed Screws can be used with the X-Post and allows for variability of placement.

- Utilize the Headed Screw Drill Guide taking care to stay within the allowable 26° cone of angulation when advancing the Guidewire through the guide
- Determine the length of the screw with "Lag Screw + Wire Guide" side of the Depth Gauge over the wire and down to the top of the Drill Guide







### STEP 7: Screw Pilot Hole

All screws are self drilling and self tapping. Pre-drilling with a cannulated drill is left up to the surgeon's discretion. **Pre-drilling for the Tapered Locking Screws:** 

- Unthread and remove the Guidewire Guide from the Top Hat Assembly
- Select the appropriate Cannulated Drill based on the desired Screw
- Advance the Cannulated Drill over the Guidewire and down to the desired depth




Screw Type and Size	Pilot Drill
4.3mm Tapered Locking	3.0mm
5.0mm Tapered Locking	3.4mm
4.5mm Headed Non-Locking	3.0mm

**NOTE:** Utilize the Headed Screw Drill Guide for the Low Profile Headed Screw (Non-Locking)

# **STEP 8: Screw Insertion**

- Prior to inserting the screw, ensure the joint is manually compressed
- Insert the screw over the Guidewire with the 3.0mm Hex Driver
- Final tightening of the Tapered Locking Screw should be applied with Two Finger pressure and care should be taken not to over tighten the construct






### **IMPLANT REMOVAL**

- Clear any tissue ingrowth from the Lag Screw
- Insert the 3.0mm Hex Driver into the Lag Screw and back out the Lag Screw by turning counterclockwise
- Insert the 3.0mm Hex Driver into the X-Post and back out the Lag Screw by turning counterclockwise







### X-Posts

Part Number	Description
SMALL X-POS	ST (AQUA)
118-70615	SMALL X-POST - 15mm
118-70620	SMALL X-POST - 20mm
118-70625	SMALL X-POST - 25mm
118-70630	SMALL X-POST - 30mm
MEDIUM X-P	OST (BLUE)
118-80620	MEDIUM X-POST - 20mm
118-80625	MEDIUM X-POST - 25mm
118-80630	MEDIUM X-POST - 30mm

### Screws

<u>JCICW3</u>	
Part Number	Description
Ø4.3 Tapered	Locking Screws
118-43026	Ø4.3 Tapered Locking Screw x 26mm
118-43028	Ø4.3 Tapered Locking Screw x 28mm
118-43030	Ø4.3 Tapered Locking Screw x 30mm
118-43032	Ø4.3 Tapered Locking Screw x 32mm
118-43034	Ø4.3 Tapered Locking Screw x 34mm
118-43036	Ø4.3 Tapered Locking Screw x 36mm
118-43038	Ø4.3 Tapered Locking Screw x 38mm
118-43040	Ø4.3 Tapered Locking Screw x 40mm
118-43045	Ø4.3 Tapered Locking Screw x 45mm
118-43050	Ø4.3 Tapered Locking Screw x 50mm
Ø5.0 Tapered	Locking Screws
118-50026	Ø5.0 Tapered Locking Screw x 26mm
118-50028	Ø5.0 Tapered Locking Screw x 28mm
118-50030	Ø5.0 Tapered Locking Screw x 30mm
118-50032	Ø5.0 Tapered Locking Screw x 32mm
118-50034	Ø5.0 Tapered Locking Screw x 34mm
118-50036	Ø5.0 Tapered Locking Screw x 36mm
118-50038	Ø5.0 Tapered Locking Screw x 38mm
118-50040	Ø5.0 Tapered Locking Screw x 40mm
118-50045	Ø5.0 Tapered Locking Screw x 45mm
118-50050	Ø5.0 Tapered Locking Screw x 50mm
Ø4.5 Low Pro	file Headed Screws (Non-Locking)
118-45126	Ø4.5 Low Profile Headed Screw x 26mm
118-45128	Ø4.5 Low Profile Headed Screw x 28mm
118-45130	Ø4.5 Low Profile Headed Screw x 30mm
118-45132	Ø4.5 Low Profile Headed Screw x 32mm
118-45134	Ø4.5 Low Profile Headed Screw x 34mm
118-45136	Ø4.5 Low Profile Headed Screw x 36mm
118-45138	Ø4.5 Low Profile Headed Screw x 38mm
118-45140	Ø4.5 Low Profile Headed Screw x 40mm
118-45145	Ø4.5 Low Profile Headed Screw x 45mm
118-45150	Ø4.5 Low Profile Headed Screw x 50mm

### Instruments

Disposable Instruments	Part Number	Description
101-00023   Cleaning Brush - 1.6mm   118-02030   Cannulated Drill - 3.0mm   118-02034   Cannulated Drill - 3.4mm   101-00013   Cannulated Drill - 4.5mm   118-02002   IO FIX 2.0 X-Ray Template   118-02076   Small X-Post Countersink   Medium X-Post Countersink   118-02077   Medium X-Post Countersink   118-02078   Headed Screw Countersink   118-02111   Clearing Trephine   Reusable Instruments   101-00009   Guidewire Holder - 1.6mm   102-00017   AO Quick Connect Handle   118-02030   3.0 Hex Driver   118-02000   Instrument Tray and Screw Caddy   118-02013   Headed Screw Drill Guide   118-02015   Clearing Tool   118-02031   Clearing Jig   118-02032   Alignment Guide   118-02039   Handle (Medium AO Ratchet)   118-02040   Depth Gauge   118-02160   Wire Guide - 1.6mm   118-02300   Drill Guide - 3.0mm   118-02300   Dri		
118-02030         Cannulated Drill - 3.0mm           118-02034         Cannulated Drill - 3.4mm           101-00013         Cannulated Drill - 4.5mm           118-02002         IO FIX 2.0 X-Ray Template           118-02076         Small X-Post Countersink           118-02077         Medium X-Post Countersink           118-02045         Headed Screw Countersink           118-02111         Clearing Trephine           Reusable Instruments         101-00009           101-00009         Guidewire Holder - 1.6mm           102-00017         AO Quick Connect Handle           118-02000         Instrument Tray and Screw Caddy           118-02001         Headed Screw Drill Guide           118-02015         Clearing Tool           118-02031         Clearing Tool           118-02032         Alignment Guide           118-02039         Handle (Medium AO Ratchet)           118-02040         Depth Gauge           118-02160         Wire Guide - 1.6mm           118-02300         Drill Guide - 3.0mm		
118-02034         Cannulated Drill - 3.4mm           101-00013         Cannulated Drill - 4.5mm           118-02002         IO FIX 2.0 X-Ray Template           118-02076         Small X-Post Countersink           118-02077         Medium X-Post Countersink           118-02045         Headed Screw Countersink           118-02111         Clearing Trephine           Reusable Instruments         101-00009           101-00009         Guidewire Holder - 1.6mm           102-00017         AO Quick Connect Handle           118-02000         Instrument Tray and Screw Caddy           118-02001         Headed Screw Drill Guide           118-02015         Clearing Tool           118-02032         Alignment Guide           118-02032         Alignment Guide           118-02039         Handle (Medium AO Ratchet)           118-02040         Depth Gauge           118-02160         Wire Guide - 1.6mm           118-02300         Drill Guide - 3.0mm	101-00023	Cleaning Brush - 1.6mm
101-00013         Cannulated Drill - 4.5mm           118-02002         IO FIX 2.0 X-Ray Template           118-02076         Small X-Post Countersink           118-02077         Medium X-Post Countersink           118-02045         Headed Screw Countersink           118-02111         Clearing Trephine           Reusable Instruments         101-00009           101-00009         Guidewire Holder - 1.6mm           102-00017         AO Quick Connect Handle           118-00300         Jo Hex Driver           118-02001         Instrument Tray and Screw Caddy           118-02013         Headed Screw Drill Guide           118-02015         Clearing Tool           118-02032         Alignment Guide           118-02039         Handle (Medium AO Ratchet)           118-02040         Depth Gauge           118-02160         Wire Guide - 1.6mm           118-02300         Drill Guide - 3.0mm	118-02030	Cannulated Drill - 3.0mm
118-02002         IO FIX 2.0 X-Ray Template           118-02076         Small X-Post Countersink           118-02077         Medium X-Post Countersink           118-02045         Headed Screw Countersink           118-02111         Clearing Trephine           Reusable Instruments         101-00009           101-00009         Guidewire Holder - 1.6mm           102-00017         AO Quick Connect Handle           118-00300         Jost Expriver           118-02001         Instrument Tray and Screw Caddy           118-02013         Headed Screw Drill Guide           118-02015         Clearing Tool           118-02032         Alignment Guide           118-02039         Handle (Medium AO Ratchet)           118-02040         Depth Gauge           118-02160         Wire Guide - 1.6mm           118-02300         Drill Guide - 3.0mm	118-02034	Cannulated Drill - 3.4mm
118-02076         Small X-Post Countersink           118-02077         Medium X-Post Countersink           118-02045         Headed Screw Countersink           118-02111         Clearing Trephine           Reusable Instruments         101-00009           101-00009         Guidewire Holder - 1.6mm           102-00017         AO Quick Connect Handle           118-00300         John Screw Caddy           118-02001         Instrument Tray and Screw Caddy           118-02013         Headed Screw Drill Guide           118-02015         Clearing Tool           118-02031         Clearing Jig           118-02032         Alignment Guide           118-02039         Handle (Medium AO Ratchet)           118-02040         Depth Gauge           118-02160         Wire Guide - 1.6mm           118-02300         Drill Guide - 3.0mm	101-00013	Cannulated Drill - 4.5mm
118-02077         Medium X-Post Countersink           118-02045         Headed Screw Countersink           118-02111         Clearing Trephine           Reusable Instruments         101-00009           Guidewire Holder - 1.6mm         102-00017           AO Quick Connect Handle         118-00030           118-02000         Instrument Tray and Screw Caddy           118-02001         Headed Screw Drill Guide           118-02015         Clearing Tool           118-02031         Clearing Jig           118-02032         Alignment Guide           118-02039         Handle (Medium AO Ratchet)           118-02040         Depth Gauge           118-02160         Wire Guide - 1.6mm           118-02300         Drill Guide - 3.0mm	118-02002	IO FIX 2.0 X-Ray Template
118-02045         Headed Screw Countersink           118-02111         Clearing Trephine           Reusable Instruments         101-00009           101-00009         Guidewire Holder - 1.6mm           102-00017         AO Quick Connect Handle           118-00030         3.0 Hex Driver           118-02000         Instrument Tray and Screw Caddy           118-02013         Headed Screw Drill Guide           118-02015         Clearing Tool           118-02031         Clearing Jig           118-02032         Alignment Guide           118-02039         Handle (Medium AO Ratchet)           118-02040         Depth Gauge           118-02160         Wire Guide - 1.6mm           118-02300         Drill Guide - 3.0mm	118-02076	Small X-Post Countersink
118-02111         Clearing Trephine           Reusable Instruments         101-00009         Guidewire Holder - 1.6mm           102-00017         AO Quick Connect Handle           118-00030         3.0 Hex Driver           118-02001         Instrument Tray and Screw Caddy           118-02013         Headed Screw Drill Guide           118-02015         Clearing Tool           118-02031         Clearing Jig           118-02032         Alignment Guide           118-02039         Handle (Medium AO Ratchet)           118-02040         Depth Gauge           118-02160         Wire Guide - 1.6mm           118-02300         Drill Guide - 3.0mm	118-02077	Medium X-Post Countersink
Reusable Instruments           101-00009         Guidewire Holder - 1.6mm           102-00017         AO Quick Connect Handle           118-00030         3.0 Hex Driver           118-02000         Instrument Tray and Screw Caddy           118-02013         Headed Screw Drill Guide           118-02015         Clearing Tool           118-02031         Clearing Jig           118-02032         Alignment Guide           118-02039         Handle (Medium AO Ratchet)           118-02040         Depth Gauge           118-02160         Wire Guide - 1.6mm           118-02300         Drill Guide - 3.0mm	118-02045	Headed Screw Countersink
101-00009 Guidewire Holder - 1.6mm  102-00017 AO Quick Connect Handle  118-00030 3.0 Hex Driver  118-02000 Instrument Tray and Screw Caddy  118-02013 Headed Screw Drill Guide  118-02015 Clearing Tool  118-02031 Clearing Jig  118-02032 Alignment Guide  118-02039 Handle (Medium AO Ratchet)  118-02040 Depth Gauge  118-02160 Wire Guide - 1.6mm  118-02300 Drill Guide - 3.0mm	118-02111	Clearing Trephine
102-00017         AO Quick Connect Handle           118-00030         3.0 Hex Driver           118-02000         Instrument Tray and Screw Caddy           118-02013         Headed Screw Drill Guide           118-02015         Clearing Tool           118-02031         Clearing Jig           118-02032         Alignment Guide           118-02039         Handle (Medium AO Ratchet)           118-02040         Depth Gauge           118-02160         Wire Guide - 1.6mm           118-02300         Drill Guide - 3.0mm	Reusable Ins	truments
118-00030       3.0 Hex Driver         118-02000       Instrument Tray and Screw Caddy         118-02013       Headed Screw Drill Guide         118-02015       Clearing Tool         118-02031       Clearing Jig         118-02032       Alignment Guide         118-02039       Handle (Medium AO Ratchet)         118-02040       Depth Gauge         118-02160       Wire Guide - 1.6mm         118-02300       Drill Guide - 3.0mm	101-00009	Guidewire Holder - 1.6mm
118-02000         Instrument Tray and Screw Caddy           118-02013         Headed Screw Drill Guide           118-02015         Clearing Tool           118-02031         Clearing Jig           118-02032         Alignment Guide           118-02039         Handle (Medium AO Ratchet)           118-02040         Depth Gauge           118-02160         Wire Guide - 1.6mm           118-02300         Drill Guide - 3.0mm	102-00017	AO Quick Connect Handle
118-02013       Headed Screw Drill Guide         118-02015       Clearing Tool         118-02031       Clearing Jig         118-02032       Alignment Guide         118-02039       Handle (Medium AO Ratchet)         118-02040       Depth Gauge         118-02160       Wire Guide - 1.6mm         118-02300       Drill Guide - 3.0mm	118-00030	3.0 Hex Driver
118-02015         Clearing Tool           118-02031         Clearing Jig           118-02032         Alignment Guide           118-02039         Handle (Medium AO Ratchet)           118-02040         Depth Gauge           118-02160         Wire Guide - 1.6mm           118-02300         Drill Guide - 3.0mm	118-02000	Instrument Tray and Screw Caddy
118-02031       Clearing Jig         118-02032       Alignment Guide         118-02039       Handle (Medium AO Ratchet)         118-02040       Depth Gauge         118-02160       Wire Guide - 1.6mm         118-02300       Drill Guide - 3.0mm	118-02013	Headed Screw Drill Guide
118-02032       Alignment Guide         118-02039       Handle (Medium AO Ratchet)         118-02040       Depth Gauge         118-02160       Wire Guide - 1.6mm         118-02300       Drill Guide - 3.0mm	118-02015	Clearing Tool
118-02039       Handle (Medium AO Ratchet)         118-02040       Depth Gauge         118-02160       Wire Guide - 1.6mm         118-02300       Drill Guide - 3.0mm	118-02031	Clearing Jig
118-02040         Depth Gauge           118-02160         Wire Guide - 1.6mm           118-02300         Drill Guide - 3.0mm	118-02032	Alignment Guide
118-02160 Wire Guide - 1.6mm 118-02300 Drill Guide - 3.0mm	118-02039	Handle (Medium AO Ratchet)
118-02300 Drill Guide - 3.0mm	118-02040	Depth Gauge
	118-02160	Wire Guide - 1.6mm
110 02240   D.II.C.:   2.4	118-02300	Drill Guide - 3.0mm
118-02340 Drill Guide - 3.4mm	118-02340	Drill Guide - 3.4mm

